



U-Shape Burner Replacement

Parts Needed: Phillips head screwdriver



Nexgrill Industries Inc.


800-913-8999

customerservice@grillservices.com


www.nexgrill.com


www.grillservices.com

19000576A0



To remove u-shape burner, locate two screws on the back of the burner and remove. Then lift the burner up and out.





Install the new burner, making sure the valve inserts into the burner pipe. Using the two screws at the back of the new burner, secure it into the bowl assembly.

